


**VX-410E/-420E Series
Operating Manual**

Controls & Connectors

LED Indicator

Glows Green	Monitor on (or Side 1, 2 switch is activated : VX-410E series only)
Blinking Green	Busy Channel (or SQL off)
Glows Red	Transmitting
Blinking Red	Battery Voltage is low
Yellow	Receiving a Selective Call



0404R-AE

Important Notice!

- Please read this manual carefully to become familiar with the features of this transceiver.
- When transmitting, hold the radio in a vertical position with its microphone 2.5 to 5 cm away from your mouth and keep the antenna at least 2.5cm away from your head and body.
- The radio must be used with a maximum operating duty cycle not exceeding 50 %, in typical Push-to-Talk (PTT) configurations. DO NOT transmit for more than 50 % of total radio use time (50 % duty cycle). Transmitting more than 50 % of the time can cause FCC RF exposure compliance requirements to be exceeded. The radio is transmitting when the red LED on the top of the radio is illuminated. You can cause the radio to transmit by pressing the PTT button or by using the VOX headset, model VC-25.
- DO NOT transmit when the radio is used in Body Worn configuration with the following accessory: belt-clip. It must be used ONLY for (1) there is a 4 cm distance from the body during transmitting, (2) monitoring purposes, using the speaker only and (3) for carrying purposes.
- Always use Vertex Standard authorized accessories.


Notice !

There are no owner-serviceable parts inside the transceiver. All service jobs must be referred to an authorized VERTEX STANDARD Service Representative. Consult your Authorized VERTEX STANDARD Dealer for installation of optional accessories.

Before You Begin

Battery Pack Installation and Removal

- To install the battery, hold the transceiver with your left hand, so your palm is over the speaker and your thumb is on the top of the belt clip. Insert the battery pack into the battery compartment on the back of the radio while tilting the Belt Clip outward, then close the Battery Pack Latch until it locks in place with a "Click."



- To remove the battery, turn the radio off and remove any protective cases. Open the Battery Pack latch on the bottom of the radio, then slide the battery downward and out from the radio while holding the Belt Clip.


Caution!

Do not attempt to open any of the rechargeable Ni-Cd packs, as they could explode if accidentally short-circuited.

Low Battery Indication

- As the battery discharges during use, the voltage gradually becomes lower. When the battery voltage becomes to low, substitute a freshly charged battery and recharge the depleted pack. The TX/BUSY indicator on the top of the radio will blink red when the battery voltage is low.
- Avoid recharging Ni-Cd batteries often with little use between charges, as this can degrade the charge capacity. We recommend that you carry an extra, fully-charged pack with you so the operational battery may be used until depletion (this "deep cycling" technique promotes better long-term battery capacity).

Display Icons & Indicators (VX-420E Only)




Operation

Preliminary Steps


- Install a charged battery pack onto the transceiver, as described previously.
- Screw the supplied antenna onto the Antenna jack. Never attempt to operate this transceiver without an antenna connected.
- If you have a Speaker/Microphone, we recommend that it not be connected until you are familiar with the basic operation of the VX-410E/-420E.

Operation Quick Start


- Turn the top panel's VOL/PWR knob clockwise to turn on the radio on.




- Turn the top panel's CH selector knob to choose the desired operating channel.




- Rotate the VOL/PWR knob to set the volume level. If no signal is present, press and hold in the Soft key assigned to "MONITOR" for more than 1 seconds; background noise will now be heard, and you may use this to set the VOL/PWR knob for the desired audio level.



- Press and hold in the Soft key assigned to "MONITOR" for more than 1 seconds (or press the MONITOR key twice) to quiet the noise and resume normal (quiet) monitoring.



- To transmit, monitor the channel and make sure it is clear. **THIS IS AN FCC REQUIREMENT!**
- To transmit, press and hold in the PTT switch. Speak into the microphone area of the front panel grille (lower left-hand corner) in a normal voice level. To return to the Receive mode, release the PTT switch.



- If a Speaker/Microphone is available, remove the plastic cap and its two mounting screws from the right side of the transceiver, then insert the plug from the Speaker/Microphone into the MIC/SP jack; secure the plug using the screws supplied with the Speaker/Microphone. Hold the speaker grille up next to your ear while receiving. To transmit, press the PTT switch on the Speaker/Microphone, just as you would on the main transceiver's body.

Note: Save the original plastic cap and its mounting screws. They should be re-installed when not using the Speaker/Microphone.

Accessories & Options

FNB-64	7.2 V 700 mAh Ni-Cd Battery
FNB-V57	7.2 V 1100 mAh Ni-Cd Battery
FNB-V57IS	Intrinsically-Safe 7.2 V 1100 mAh Ni-Cd Battery
FNB-V67LI	7.4 V 1600 mAh Lithium-Ion Battery
FBA-25A	Alkaline Battery Case
NC-77B	120 VAC Overnight Desktop Charger
NC-77C	220-240 VAC Overnight Desktop Charger
NC-77U	230 VAC Overnight Desktop Charger
VAC-800	Desktop Rapid Charger (for FNB-64/-V57/-V57IS)
VAC-810	Desktop Rapid Charger (for FNB-V67LI)
VAC-6800	6-unit Multi Charger
MH-45^{B4B}	Speaker/Microphone
MH-37^{A4B}	Earpiece Microphone
VC-25	VOX Headset
VCM-1	Mobile Mounting Bracket (for VAC-800/-810)
CT-42	PC Programming Cable
CT-27	Radio to Radio Programming Cable
CE64	Programming Software
VTP-50	VX-Trunk Unit
FVP-25	Encryption/DTMF pager Unit
FVP-35	Encryption Unit (Rolling code voice scrambler)
DVS-5	Voice Storage Unit
ATV-8A	VHF Antenna, 134-151 MHz (Stubby)
ATU-8B	VHF Antenna, 150-163 MHz (Stubby)
ATU-8C	VHF Antenna, 161-174 MHz (Stubby)
ATV-6XL	VHF Antenna, 134-174 MHz (Untuned)
ATU-6C	UHF Antenna, 440-470 MHz
ATU-6D	UHF Antenna, 450-490 MHz
MDC1200	Digital ANI encoder Unit

VERTEX STANDARD CO., LTD.
4-8-8 Nakameguro, Meguro-Ku, Tokyo 153-8644, Japan

VERTEX STANDARD US Headquarters
10900 Walker Street, Cypress, CA 90630, U.S.A.

YAESU EUROPE B.V.
P.O. Box 75525, 1118 ZN Schiphol, The Netherlands

YAESU UK LTD.
Unit 12, Sun Valley Business Park, Winnall Close
Winchester, Hampshire, SO23 0LB, U.K.

VERTEX STANDARD HK LTD.
Unit 5, 20/F., Seaview Centre, 139-141 Hoi Bun Road,
Kwun Tong, Kowloon, Hong Kong

